



ADDENDUM TO CRC029_CRC029X RICE COOKERS & CSC024_CSC024X MULTI-COOKERS

Thermal cut-out

In addition to the Boil Dry safety feature, your Rice Cooker/Multi-Cooker is fitted with a resettable thermal cut-out. If the appliance should overheat, the thermal cut-out will interrupt the power supply.

After the thermal cut-out has operated:

- Switch off the appliance
- Unplug from the supply socket
- Allow to cool down for 30-35 minutes

To resume normal use, plug the appliance back into the supply socket and press the Standby button.

CRC029_CRC029X_CSC024_CSC024X_Add_Rev1 05/15

94001-0 UKPUL
P.N.183647



ADDENDUM TO CRC029_CRC029X RICE COOKERS & CSC024_CSC024X MULTI-COOKERS

Thermal cut-out

In addition to the Boil Dry safety feature, your Rice Cooker/Multi-Cooker is fitted with a resettable thermal cut-out. If the appliance should overheat, the thermal cut-out will interrupt the power supply.

After the thermal cut-out has operated:

- Switch off the appliance
- Unplug from the supply socket
- Allow to cool down for 30-35 minutes

To resume normal use, plug the appliance back into the supply socket and press the Standby button.

CRC029_CRC029X_CSC024_CSC024X_Add_Rev1 05/15

94001-0 UKPUL
P.N.183647